Chemical Engineering 412

Introductory Nuclear Engineering

Lecture 19 Nuclear Reactor Theory IV Nuclear Kinetics



Spiritual Thought

"When we put God first, all other things fall into their proper place or drop out of our lives. Our love of the Lord will govern the claims for our affection, the demands on our time, the interests we pursue, and the order of our priorities.

We should put God ahead of *everyone else* in our lives."

President Ezra Taft Benson



Roadmap



VO, U

Objectives

- Understand the simple, "big picture" of kinetics
- Understand how delayed neutrons/precursors work
- Understand, recognize and do calculations relating to feedback coefficients
- Understand reactor "control strategies"
- Understand xenon peak phenomena



General Transient Problem





Prompt Neutrons

- Lifetime, l_p , is time between emission and absorption.
- Neutrons in thermal reactors:
 - Spend more time (most of l_p) in the thermal regime
 - Travel further as fast neutrons

 $t_d = t_{dM}(1 - f)$

• Average lifetime of a thermal neutron in an infinite reactor is the mean diffusion time, t_d , and is approximately the same as l_n in an infinite reactor. $l_p \approx t_d$

TABLE 7.1APPROXIMATE DIFFUSIONTIMES FOR SEVERAL MODERATORS

Moderator	t_d , sec
H ₂ O	2.1×10^{-4}
D ₂ O*	4.3×10^{-2}
Be	3.9×10^{-3}
Graphite	0.017

*With 0.25% H₂O impurity.



In fast reactors, prompt neutron lifetimes are much shorter, on the order of 10⁻⁷ seconds

Simple Kinetics Model

$$\Delta n(t) \equiv \ell_p \frac{dn(t)}{dt} = \left(k_{eff} - 1\right)n(t)$$
$$\frac{dn(t)}{dt} = \frac{k_{eff} - 1}{\ell_p}n(t)$$
$$\Rightarrow n(t) = n(0) \exp\left(\frac{k_{eff} - 1}{\ell_p}t\right)$$

• For ²³⁵U

•
$$\ell_p = 2.1 \times 10^{-4} \text{ s}$$

- $k_{eff} 1 = 0.001$
- and t = 1s,



 $n/n^0 = 117$ (22,027 if $\ell' = 10^{-4}$ as in text) Far too rapid to control!!!

Reactors with delayed neutrons

Delayed neutrons: β is fraction of total neutrons $\overline{\ell}_p = (1 - \beta)\ell_p + \beta(\ell_p + \tau) \approx \ell_p + \beta\tau$ τ is lifetime of delayed neutrons = $\frac{T_{1/2}}{\ln 2} \approx 12.8 s$

 τ is meane of delayed neutrons = $\frac{1}{\ln 2} \approx 12.8 s$ For $\delta k \ll \beta$

$$\frac{n(t)}{n_0} = \exp\left(\frac{k_{eff} - 1}{\overline{\ell}_p}\right) = \exp\left(\frac{t}{\overline{T}}\right) \frac{1}{\overline{\ell}_p} = \frac{\beta\tau}{k_{dff} - 1} = \frac{\beta\tau}{\delta k}$$

- For ²³⁵U, T = 83 s, k_{eff} -1 = 0.001,
- $n/n^0 = 1.012$
 - This can be controlled!

Delayed Neutrons

TABLE 3.5 DELAYED NEUTRON DATA FOR THERMAL FISSION IN ²³⁵U*

Group	Half-Life (sec)	Decay Constant (l_i, \sec^{-1})	Energy (ke V)	Yield, Neutrons per Fission	Fraction (β_i)
1	55.72	0.0124	250	0.00052	0.000215
2	22.72	0.0305	560	0.00346	0.001424
3	6.22	0.111	405	0.00310	0.001274
4	2.30	0.301	450	0.00624	0.002568
5	0.610	1.14		0.00182	0.000748
6	0.230	3.01		0.00066	0.000273
				Total	yield: 0.0158
				Total delayed fraction	on (β) 0.0065

*Based in part on G. R. Keepin, *Physics of Nuclear Kinetics*, Reading, Mass.: Addison-Wesley, 1965.

TOUNG UN I FIRST

For 1-group model, $T_{\frac{1}{2}}$ for ²³⁵U is about 8.87 s and τ is about 12.8 s.

Delayed Neutron Fractions

0	235 U		233 U		²³⁹ Pu	
Group	Half-life (s)	fraction β_i	Half-life (s)	fraction β_i	Half-life (s)	fraction β_i
1	55.7	0.00021	55.0	0.00022	54.3	0.00007
2	22.7	0.00142	20.6	0.00078	23.0	0.00063
3	6.22	0.00127	5.00	0.00066	5.60	0.00044
4	2.30	0.00257	2.13	0,00072	2.13	0.00068
5	0.610	0.00075	0.615	0.00013	0.618	0.00018
6	0.230	0.00027	0.277	0.00009	0.257	0.00009
total		0.0065	-	0.0026	-	0.0021







Reactivity and Worth

$$\rho \equiv \frac{k_{eff} - 1}{k_{eff}} = \frac{\delta k}{k_{eff}}$$

reactivity ρ and δk

 $k(\$) \equiv \frac{\rho}{\beta}$ β is delayed neutron fraction worth can be measured in units of k(\$) or k

- cents?
- Percent Mil?



Reactivity Equation Solutions

$$A_{1} = A_{1} \exp(\omega_{1}t) + A_{2} \exp(\omega_{2}t)$$

dominant term as $t \rightarrow \infty$

 ω_p

approaches 0 rapdily

 $+\frac{\omega}{1+\omega I_{\rho}}\sum_{i=1}^{0}\frac{\beta_{i}}{\omega+\lambda_{i}}$

General solution for single group of delayed neutrons

Definition of reactor or stable period

General solution for single group of delayed neutrons

Reactivity equation for six group model



Power Changes

$$T = \frac{\beta\tau}{\delta k} = \frac{\beta\tau}{keff \cdot \rho} = \frac{\tau}{keff \cdot k(\$)} \sim \frac{\tau}{k(\$)}$$

- T = Reactor Period (units of time)
 - Time required to increase reactor power (or neutron flux) by 2.72
- Integrate solution with specific values (initial time power to final time/power

$$\frac{t}{T} = ln \left[\frac{P(t)}{P(0)} \right]$$



Reactivity Equation Solutions

$$T = \frac{\overline{l}}{k_{eff} - 1} = \frac{\overline{l}}{\delta k} = \frac{\beta \tau}{\delta k} =$$

<u>**Reactor period**</u> - The time required for a neutron population to change by a factor of e

$$k_{eff} = 1 + \delta k = 1 + \frac{\beta \tau}{T}$$
 τ =Lifetime of delayed neutrons ~12.8s (U235)

$$T = \frac{\beta\tau}{\delta k} = \frac{\beta\tau}{k_{eff} - 1} = \frac{\beta\tau}{k_{eff}\rho} = \frac{\tau}{k_{eff}\rho(\$)} \approx \frac{\tau}{\rho(\$)}$$

 $\phi(t) = exp\left(\frac{t}{T}\right)$

Remember, Flux is proportional to power....

$$C \cdot P(t) = exp\left(\frac{t}{T}\right)$$
 $\frac{t}{T} = ln\left(\frac{P(t) \cdot C}{P(0) \cdot C}\right)$ $\frac{P(t)}{P(0)} = exp\left(\frac{t}{T}\right)$



Example

 Following a reactor scram in which all the control rods are inserted into a power reactor, how long is it before the reactor power decreases to 0.0001 of the steady-state power prior to shutdown? (Assume a reactor period of -80 s)



1-level Model Parameters

	β	$T_{\frac{1}{2},d}(s)$	$\tau_d(s)$
²³² Th	0.0203	6.98	10.07
²³³ U	0.0026	12.4	17.89
²³⁵ U	0.0064	8.82	12.72
²³⁸ U	0.0148	5.32	7.68
²³⁹ Pu	0.002	7.81	11.27
²⁴¹ Pu	0.0054	104.1	150.18
²⁴¹ Am	0.0013	10	14.43
²⁴³ Am	0.0024	10	14.43
²⁴² Cm	0.0004	10	14.43



Source: Laboratoire de Physique Subatomique et de Cosmologie

Exploration 1

• What if we add -\$0.1 to AP1000 core?



OUNG

FOUNDE

BYU

Exploration 2

• What if we add \$0.1 to AP1000 core?





Exploration 3

 What if we add \$0.1 to AP1000 core, then after 10 seconds we add -\$0.1?





Reality





Power Plant Operation

- Try to achieve "steady state" operation at all times
- Set up core and fuel to provide minimal changes
- Despite this, still have three scales of change
 - 1. Short Term (Grid load transients)
 - 2. Intermediate Term (Fuel composition changes)
 - 3. Long Term (Burnup & Depletion)



K_{eff} vs. time curve for Power plant?



Three Time Scales (short)

- Short Time Constant (load change)
 - An abrupt change in steam demand/load.
 - A load change is seen as:
 - Reactor pressure change in the BWR
 - Reactor temperature change in a PWR.
 - Higher loads lead to higher pressures/temperatures.
- Assumptions
 - Assumes a uniform multiplicative change everywhere
 - Spatial variations in time in the reactor are not considered
 - (This method is called point kinetics.)



Three Time Scales (intermediate)

- Intermediate Time Constant (core composition change)
 - Changing fission product concentrations
 - Generation rates and destruction/decay rates.
 - Many fission products have measurable thermal neutron cross sections $f = \frac{\Sigma_a^F}{\Sigma_a^F + \Sigma_a^{NF}(V^{NF}/V^F)(\phi^{NF}/\phi^F)}$
 - **Change** the value of k (and k_{∞}).
 - Point kinetics can be used if spatial variations in concentrations are negligible.
 - Otherwise, detailed spatial and temporal equations must be used!



Three Time Scales (long)

- Long Time Constant (Fuel Depletion)
 - Treated as a series of steady-state problems

$$D\nabla^2 \phi - \Sigma_a \phi = -\lambda \nu \Sigma_f \phi$$

- Two things are adjusted to maintain $\lambda = 1$ (i.e. $\lambda = 1/k$)
 - Material buckling
 - Reactor dimensions
 - If λ ≠ 1, the equation is not valid
 Why?
- In operating reactor, cannot change dimensions (much)
 - *k* is adjusted slowly in time by changing chemical shim conc.
 - Chemical shim is an isotope that absorbs neutrons in the reactor
 - k is also adjusted via the control rods.
- Managing fuel consumption is a classical example of this type of transient

