

Chemical Engineering 412

Introductory Nuclear Engineering

Lecture 17

Nuclear Reactor Theory II

6 Factors and Reactor Equation



Spiritual Thought

“The building up of Zion is a cause that has interested the people of God in every age;... but... we are the favored people that God has made choice of to bring about the Latter day glory;... we ought to have the building up of Zion as our greatest object.”


-Elder Kim B. Clark

“Wherever we are, whatever city we may live in, we can build our own Zion by the principles of the celestial kingdom, and ever seek to become the pure in heart.”

-Elder David R. Stone



Roadmap




Objectives


- Know the 6 factor formula (+ each factor)
- Know differences between heterogeneous and homogeneous cores
- Know the 6 factor formula (+ each factor)
- Understand General trends of 6 factors
- Know the 1 group reactor equation
- Be familiar with neutron diffusion theory



k_{∞} variation with fuel:modifier ratio (HM/H)



k_{∞} variation with (HM/H)



Neutron Cycle Parameters

Natural uranium and moderator in homogeneous reactor:

| Moderator | $(N^M / N^U)_{\text{opt}}$ | ϵ | η | f | p | k_{∞} |
|------------------|----------------------------|------------|--------|-------|-------|--------------|
| H ₂ O | 1.64 | 1.057 | 1.322 | 0.873 | 0.723 | 0.882 |
| D ₂ O | 272 | 1.000 | 1.322 | 0.954 | 0.914 | 1.153 |
| Be | 181 | 1.000 | 1.322 | 0.818 | 0.702 | 0.759 |
| C | 453 | 1.000 | 1.322 | 0.830 | 0.718 | 0.787 |

Heavy water moderation allows homogeneous reactor operation with natural uranium. CANDU reactors take advantage of this in principle – though no reactor is a homogeneous reactor.

A Few Parameters

$\nu = \text{neutrons / fission}$

Total (prompt and delayed) neutrons
produced per fission

$$\alpha = \frac{\sigma_{\gamma}}{\sigma_f}$$

Capture to fission ratio

$$\eta = \nu \frac{\sigma_f}{\sigma_a} = \nu \frac{\sigma_f}{\sigma_{\gamma} + \sigma_f} = \frac{\nu}{1 + \alpha}$$

Neutrons released per absorption
(> 1 converter, > 2 breeder)

$$k = \frac{\text{neutrons after one generation}}{\text{original neutrons}}$$


Multiplication factor

$$C = \frac{\text{fissile atoms produced}}{\text{fissile atoms consumed}}$$

conversion/breeding ratio
(>1 breeder reactor)



Typical Parameter Variation



Homogeneous reactor, 2% enrichment



Example – Homogeneous, ^{239}Pu

- Pure ^{239}Pu fuel and reactor is a water-moderated ($\frac{N^{NF}}{N^F}=1$), water-cooled bare infinite cylinder. How large of radius for criticality?
 - $\epsilon p \eta f P_{NL}^f P_L^{th} = 1 = k_{eff}$
 - $\epsilon p \approx 1$ (pure fuel makes p close to 1 and ϵ slightly greater than 1)
 - $\eta = 2.11$ (Fuel property – Table 10.1)
 - $f = (749 + 271) / \left[(749 + 271) + 2 \left(0.333 + \frac{0.00019}{2} \right) \left(\frac{N^{NF}}{N^F} \right) \right] = 0.999$
 - $P_{NL}^{th} = \frac{1}{L^2 B_c^2} = \frac{1}{L_M^2 (1-f) B_c^2} = \frac{1}{2.85^2 (0.001) \left(\frac{2.405}{R} \right)^2}$
 - $P_{NL}^f = \exp(-B_c^2 \tau) = \exp \left(- \left(\frac{2.405}{R} \right)^2 27 \right)$

$$\epsilon p \eta f P_{NL}^f P_L^{th} = 1 = 1(2.11)f \frac{\exp \left(- \left(\frac{2.405}{R} \right)^2 27 \right)}{2.85^2 (1-f) \left(\frac{2.405}{R} \right)^2} = 68.8 R^2 \frac{N^F}{N^{NF}} \exp \left(- \frac{156.6}{R^2} \right)$$




Heterogeneous vs. homogeneous

- Heterogeneous cores change the reactor parameters :
 - p resonance escape probability
 - increases significantly
 - neutrons slow primarily in the moderator
 - no (or controlled amounts of) highly absorbing nuclides.
 - ϵ fast fission
 - Increases slightly
 - fast neutrons are primarily surrounded by fissionable and fissile nuclides
 - f thermal utilization at fixed fuel loading (N^F / N^{NF})
 - Lower in heterogeneous reactor
 - Thermal neutron flux in fuel rod is less than that in moderator
 - η thermal fission factor
 - unchanged
 - depends only on the type of fuel
 - P_{NL}^f, P_{NL}^{th} Leakage probabilities
 - Unchanged
 - Depend primarily on reactor shape and size



Dependence on Design



Fuel with carbon moderator

local optimum – heterogeneous
cores allow even graphite-
moderated reactors to operate on
natural uranium

| Pitch a (cm) | ϵ | η | f | p | k_{∞} |
|-------------------|------------|--------|-------|-------|--------------|
| 12 | 1.027 | 1.322 | 0.972 | 0.742 | 0.979 |
| 16 | 1.027 | 1.322 | 0.947 | 0.848 | 1.090 |
| 20 | 1.027 | 1.322 | 0.916 | 0.900 | 1.120 |
| 21 | 1.027 | 1.322 | 0.907 | 0.909 | 1.121 |
| 22 | 1.027 | 1.322 | 0.898 | 0.917 | 1.119 |
| 26 | 1.027 | 1.322 | 0.860 | 0.940 | 1.098 |
| 30 | 1.027 | 1.322 | 0.818 | 0.955 | 1.060 |

One-group Reactor Equation

Mono-energetic neutrons (Neutron Balance)

$$D\nabla^2\phi - \Sigma_a\phi + s = -\frac{1}{v}\frac{\partial\phi}{\partial t} \quad v \text{ is neutron speed}$$

$$\text{For reactor, } s = \nu\Sigma_f\phi \quad \nu \text{ is neutrons/fission}$$

In eigenfunction form and at steady state

$$D\nabla^2\phi - \Sigma_a\phi + \frac{\nu}{\textcolor{red}{k}}\Sigma_f\phi = 0$$

$$\Rightarrow \nabla^2\phi - \frac{\Sigma_a - \frac{\nu}{\textcolor{red}{k}}\Sigma_f}{D}\phi = \nabla^2\phi + \textcolor{red}{B}^2\phi = 0$$

